



产品参数

电流	0-5.1A	电压	4-30V
计时	0-99小时	功率	0-155W
毫安时	0-99999mAh	内部温度	0-80度
分组	0-9组	颜色	黑色、白色

监测仪面板展示




快速双击按键可旋转显示内容,方便观看



单击按键可查看1-9组保存的充电数据
长压按键3秒可清除单组保存的充电数据

USB Type-C测试仪 使用说明书



- | | | |
|-------------|-------------|---------|
| 1. 电流 | 2. 电压 | 3. 计时 |
| 4. 功率 | 5. 毫安时 | 6. 内部温度 |
| 7. 分组 | 8. 充电电流向标 | 9. 操作按键 |
| 10. Type-c公 | 11. Type-c母 | |

产品参数

- | | |
|-------------------|--------------|
| 1. 电流:0-5.1A | 2. 电压:4-30V |
| 3. 计时:0-99小时 | 4. 功率:0-155W |
| 5. 毫安时:0-99999mAh | 6. 内部温度0-80度 |
| 7. 分组0-9组 | |

使用说明

- 1: 单击按键可查看1-9组保存的充电数据
- 2: 长按按键3秒可清除单组保存的充电数据
- 3: 快速双击按键可旋转显示内容, 方便观看


电流校准方法

长按按键不放, 再用电源插头插入测试仪Type-C母座(如图11)等显示屏正常显示后校准已完成。

注意

在电流校准时, 测试仪不能连接任何负载。

USB Type-C tester operating manual



- | | | |
|-----------------------|-------------------------|----------------------|
| 1. Current | 2. Voltage | 3. Timing |
| 4. Power | 5. Capacity | 6. Inner temperature |
| 7. Divide into groups | 8. Direction of current | |
| 9. keystroke | 10. Type-C plug | 11. Type-C socket |

Product Parameter

- | | |
|----------------------------------|------------------------------|
| 1. Current: 0-5.1A | 2. Voltage: 4-30V |
| 3. Timing: 0-99 hours | 4. Power : 0-155W |
| 5. Capacity: 0-99999mAh | 6. Inner temperature: 0-80°C |
| 7. Divide into groups: 0-9 group | |

Directions for use

- 1: Click the button to view 1-9 sets of charging data.
- 2: Long press the button for 3 seconds to remove a set of charging data.
- 3: Double-click the button to rotate the screen to view.

Currents calibration method:

Please long press buttons don't let go, and then use the plug insert tester Type-C socket (picture-11). When the display screen can display properly, reset has been completed.

Notice

In currents calibration, the test instrument not connect any load.